


TS5520 Series Spray Valve



Seal Repair Kit = 5520-SEALKIT

Includes 1 x 3, 4, 11, 19, 21 and 1 x 22 - TSD931-75 - (TSD1003-16 Shown)

Valve Repair Kit = 5520-VALVEKIT

Includes 1 x 2, 3, 4, 9, 11, 12, 17, 19, 21, 22 - TSD931-75 - (TSD1003-16 Shown) and 2 x 10

U-Seal Insertion Tool = 5420-SIT

Nozzle Seat Tool = TSD1113-28

Lubrication: All O-Rings & seals must be lubricated with Bimba HT-99, or equivalent, with the exception of TSD400-70, which must remain dry.

Item	Part Number	Description	Item	Part Number	Description
1	TSD1120-2	Retaining Ring, Small	12	5520-000-010	Needle/Piston Assembly
2	TSD1109-45	Nylon Washer	13	5520-000-001	Air Cylinder
3	TSD1400-006A	O-Ring, Buna	14	918-000-048	Mounting Bracket
4	TSD1400-013A	O-Ring, Buna	15	2800-0634	Mounting Screw
5	TSD1003-20	Air Fitting, 4mm, Elbow	16	5520-000-018	Spray Cone Cap
6	A0100478	Air Hose/Connector Assy, 4mm	17	5520-000-020	Nozzle, Inc. Seat
7	TSD1150-34	Spring	18	T1000598	Nozzle Seat
8	5520-000-007	End Cap	19	TSD1400-008A	Nozzle Adaptor O-Ring, Buna
9	TSD1120-15	Retaining Ring, Large	20	5520-000-002	Body
10	TSD1109-43	Mylar Washer	21	TSD400-70	U-Cup Seal
11	TSD1400-208A	Piston O-Ring, Buna	22	TSD1003-16	Compression Fitting